

ADD-A-BATHROOM

Unit 1, 18 Francis Rd. Wingfield. South Australia. 5013

Ph: 1300 559 121

info@addabathroom.com.au

www.addabathroom.com.au

Installation overview for Add-A-Bathroom assembled bathrooms

Note that this overview is provided for general information purposes only and should not be relied upon without professional advice about your personal situation and installation requirements. As this overview does not take personal circumstances or local regulations into account and as any installation is beyond the control of Add-A-Bathroom, no responsibility is accepted nor warranty implied by Add-A-Bathroom (or its affiliated entities) by the publishing or use of this overview.

Add-A-Bathroom assembled bathrooms have been manufactured, assembled and checked in our modern production facilities and are normally supplied assembled ready for installation on-site. **Before installing an Add-A-Bathroom product read the full installation guide supplied with the bathroom; available online or from Add-A-Bathroom.** Note that only basins with inbuilt overflow protection are to be fitted.

No specialised tools are required to install an Add-A-Bathroom assembled bathroom. Installation of our bathrooms usually requires 2 competent people. All electrical and plumbing work must be performed by appropriately licensed contractors.

The bathrooms are supplied fully assembled, and will have been fitted with a combination of pipe-work, electrical, bathroomware and internal accessories as per individual order. Before ordering, ensure that there is sufficient access (and labour) so the assembled bathroom can be manoeuvred to the installation site. *(If this presents difficulty, the pre-fitted bathroom can be supplied disassembled as a 'flat pack', ready for on-site assembly. Please contact Add-A-Bathroom for more details).*

- Have your plumber install any required on-site sewer and pipe work to suit your new bathroom.
- If a window, larger door, etc. is to be installed, accurately mark the panels with a fine marker. Cut the bathroom wall panels with a fine carborundum (or smooth diamond) disc on an angle grinder.
- Manoeuvre the bathroom into its final position and check that the unit is level. It is important to bed the module into a slurry base to make sure it sits evenly and does not rock or move. We suggest a flexible tile adhesive that is suitable to provide minimum 6mm bed depth. Screed this onto the sub floor as if you were spreading it for tiling, then lift the unit onto the area and settle it in. If it is too awkward to lift into position this can be achieved by sliding the unit in on timber battens or lengths of conduit. When the unit is in its final position pull the battens out letting the unit settle.
- Connect the sewer pipework first, then the hot and cold plumbing to the connection points.
- Construct standard stud wall framing around exposed walls of the bathroom and secure the wall frame with straps or cleats to the flanges of the bathroom.
- Create door opening and frame in studwork to suit required door installation.
- If not pre-fitted at our factory, have a suitably qualified electrician install or connect electrical wiring and fittings; this may need to be pre-done prior to placing the unit into its final position.
- Install plasterboard or your desired external wall lining to the stud wall framing.
- Install door jamb. (A 720mm cavity sliding door kit works well.)
- Final fit any electrical and internal accessories not pre-fitted at our factory.
- Hang door, finish and paint externals and hang your towels. Job done!

Any questions? Call us on 1300 559 121, or email info@addabathroom.com.au

Warranty

*Add-A-Bathroom is wholly owned by Fibre Composites International Pty Ltd (the Company).

In the event of any failure within a time period of five years from date of initial sale or shipment (whichever occurs sooner) of an Add-A-Bathroom* manufactured product (the Product) and such failure is caused by the direct result of a defect in the material or manufacture of the Product, the Company will at its sole option replace or repair, supply an equivalent product, or pay for doing one of these.

This warranty does not apply where the Product has been used in any manner not in accordance with the Company's instructions, nor the reuse of the Product after its initial installation. Installation and maintenance must be in accordance with the relevant Add-A-Bathroom technical and installation guides; current copies are available by phoning (08) 8260 7729. Add-A-Bathroom recommends that only those products, components and systems recommended by it be used. The Company will need to be satisfied that any defect in its Product is directly attributable to material or manufacture defect (and not another cause) before this warranty applies.

Where Add-A-Bathroom supplies product or equipment manufactured or imported by a third party (OEM) then the individual OEM supplier's warranty will apply.

Other than as expressly set out in this warranty and guarantees that cannot be excluded under The Australian Consumer Law (Schedule 2 of the Competition and Consumer Act 2010) (and any other law), the Company excludes all other warranties and guarantees with regard to the Product. To the extent that it is able to do so, the Company excludes all liability for loss and damage (including consequential loss) in connection with the Product. The benefits of this warranty are in addition to other rights or remedies of the consumer under the law in relation to the goods or services to which the warranty relates.

Notification of a warranty claim must be made to the Company prior to any return, repair or modification of the Product. Unapproved repairs or modifications will void all warranties.

Where any defect or failure should ordinarily have been noticeable prior to the assembly or installation of the Product, then any warranty, repair or replacement that may apply will be based upon an unassembled and/or uninstalled Product. Any damage resulting from (however caused) impact or abrasion after assembly or installation commences is specifically excluded from all warranties. Visible damage to gelcoat surfaces must be reported prior to the commencement of assembly, or in the case of an assembled product, prior to commencement of installation and in any event within seven days of despatch of the Product from the Add-A-Bathroom facility.

To make a claim under this warranty, you must contact Add-A-Bathroom on (08) 8260 7729. All expense of claiming under the warranty will be borne by the person making the claim.

The Company may require the provision of documentation supporting the claim.

The sale, supply and warranty of the Company's Products shall be governed by the laws of South Australia and is only applicable to products purchased for use within the Commonwealth of Australia. Please contact the relevant import agent for local warranty details.