

# ADD-A-BATHROOM

**Fibre Composites International Pty Ltd**

1/18 Francis Road. Wingfield. S.A. 5013

Phone: 1300 559 121

email: [info@addabathroom.com.au](mailto:info@addabathroom.com.au)

Web: [www.addabathroom.com.au](http://www.addabathroom.com.au)

## **Floor waste installation instructions.**

Apply silicone sealant to the underside of the top flange of the floor waste.

Fit rubber washer and rear collar provided to the under side of the bathroom floor and fit back nut to the floor waste and hand tighten. Do not over tighten.

